

TANNIN TABLET COUNT



Notes		Health & Safety	
Please read before proceeding with the test.		Refer to R & S phrases on individual bottles.	
When performing the test hold the dropper bottles exactly upside down and allow drops to form slowly and fall off under their own weight.		Wear protective gloves and safety goggles when performing any tests using corrosive, harmful or irritant reagents.	
Do not shake off drops as this will affect the accuracy of the test.		Do not ingest.	
Transfer 50ml of filtered sample to the test jar.	Add 2 Tannin No1 tablets. Cap the jar and shake to disintegrate the tablets.	Add 1 Tannin No2 tablet. Cap the jar and shake to disintegrate the tablet.	Repeat with Tannin No2 tablet until a pink colour persists for 1 minute.



N.B. Colours may vary depending on sample and test conditions.

Tannin mg/l(ppm) = Number of Tannin No2 Tablets used X 20

Tannin Index = Numer of Tannin No2 Tablets used X 2